
INSTALLATION INSTRUCTIONS



Secure Storage Cabinet



PAC735

DISCLAIMER

Milestone AV Technologies and its affiliated corporations and subsidiaries (collectively "Milestone"), intend to make this manual accurate and complete. However, Milestone makes no claim that the information contained herein covers all details, conditions or variations, nor does it provide for every possible contingency in connection with the installation or use of this product. The information contained in this document is subject to change without notice or obligation of any kind. Milestone makes no representation of warranty, expressed or implied, regarding the information contained herein. Milestone assumes no responsibility for accuracy, completeness or sufficiency of the information contained in this document.

Chief® is a registered trademark of Milestone AV Technologies. All rights reserved.



WARNING: A WARNING alerts you to the possibility of serious injury or death if you do not follow the instructions.




CAUTION: A CAUTION alerts you to the possibility of damage or destruction of equipment if you do not follow the corresponding instructions.



WARNING: Failure to read, thoroughly understand, and follow all instructions can result in serious personal injury, damage to equipment, or voiding of factory warranty! It is the installer's responsibility to make sure all components are properly assembled and installed using the instructions provided.

WARNING: Exceeding the weight capacity can result in serious personal injury or damage to equipment! It is the installer's responsibility to make sure the combined weight of all equipment stored within the PAC735 does not exceed 40 lbs (18.14 kg).

DIMENSIONS




Installation Instructions PAC735


LEGEND

	Tighten Fastener	Pencil Mark
G	Apretar elemento de fijación	Marcar con lápiz
	Befestigungsteil festziehen	Stiftmarkierung
	Apertar fixador	Marcar com lápis
	Serrare il fissaggio	Segno a matita
	Bevestiging vastdraaien	Potloodmerkteken
	Serrez les fixations	Marquage au crayon
	Loosen Fastener	Drill Hole
\bigcirc	Aflojar elemento de fijación	Perforar
	Befestigungsteil lösen	Bohrloch
	Desapertar fixador	Fazer furo
	Allentare il fissaggio	Praticare un foro
	Bevestiging losdraaien	Gat boren
	Desserrez les fixations	Percez un trou
	Phillips Screwdriver	Adjust
	Destornillador Phillips	Ajustar
	Kreuzschlitzschraubendreher	Einstellen
	Chave de fendas Phillips	Ajustar
	Cacciavite a stella	Regolare
	Kruiskopschroevendraaier	Afstellen
	Tournevis à pointe cruciforme	Ajuster
0	Open-Ended Wrench	Remove
	Llave de boca	Quitar
	Gabelschlüssel	Entfernen
	Chave de bocas	Remover
	Chiave a punte aperte	Rimuovere
	Steeksleutel	Verwijderen
	Clé à fourche	Retirez
	By Hand	Optional
	A mano	Opcional
	Von Hand	Optional
	Com a mão	Opcional
	A mano	Opzionale
	Met de hand	·
		Optie
	À la main	En option
	Hex-Head Wrench	Security Wrench
	Hex-Head Wrench Llave de cabeza hexagonal	Llave de seguridad
M	Hex-Head Wrench	
D	Hex-Head Wrench Llave de cabeza hexagonal	Llave de seguridad
	Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel	Llave de seguridad Sicherheitsschlüssel
	Hex-Head Wrench Llave de cabeza hexagonal Sechskantschlüssel Chave de cabeça sextavada	Llave de seguridad Sicherheitsschlüssel Chave de segurança

TOOLS REQUIRED FOR INSTALLATION



PARTS



Installation Instructions PAC735

Assembly And Installation

Assemble Base Support

1. Place left wedge plate (B) and right wedge plate (C) on a flat surface with threaded bolts facing up. (See Figure 1)

- Place front cross bar (E) and rear cross bar (F) on top of wedge plates and insert bolts through corresponding holes on cross bars. (See Figure 1)
- Install eight 5/16-18" hex nuts (J) over each threaded bolt and tighten until cross bars are secured to wedge plates. (See Figure 1)




Figure 1

Attach Base Support to Cart/Stand

 Partially install four 5/16-18 x 1" button head cap screws into holes on wedge plates. DO NOT TIGHTEN! (See Figure 2)

NOTE: Screws should protrude approximately 1/8" beyond wedge plate edge in order to comfortably sit on cart/ stand grooves in next step.




Figure 2

- 2. Place support plate inside legs of cart/stand. (See Figure 3)
- 3. Thread four 5/16-18 x 1" button head cap screws (H) from Step 1 further into cart/stand until base support is secured to cart/stand. (See Figure 3)




Figure 3

Mount Storage Cabinet

 Place storage cabinet (A) on top of base support. (See Figure 4)




Figure 4

- 2. Place clamp bracket (D) around cart/stand and line up with holes on back of storage cabinet (A). (See Figure 5)
- Insert four 5/16-18 x 5/8" button head cap screws (G) through clamp bracket holes and into holes on back of storage cabinet (A). (See Figure 5)




Figure 5

 Open either door on accessory to install remaining four 5/ 16-18" hex nuts (J) onto screws (G) until accessory is fully secured to cart/stand. **NOTE:** Up to three storage cabinets can be stacked vertically on top of each other per cart/stand. Repeat steps 1-4 for additional cabinets and use holes on top of cabinets to bolt cabinets together.

Rack Installation (Optional)

- 1. Open windowed door.
- 2. Slide rack equipment (not included) into storage cabinet.

NOTE: Each storage cabinet supports 19" (483 mm) wide rack mount equipment and has a capacity of 4 U.

Use #10-32 cage nuts (not included) to secure storage racks to storage cabinet. Installation Instructions PAC735



Our Mounts. Your Vision.

Chief Manufacturing, a products division of Milestone AV Technologies

8807-002004 REV 00 ©2009 Milestone AV Technologies, a Duchossois Group Company www.chiefmfg.com 05/09 **USA/International**

Europe

A 8401 Eagle Creek Parkway, Savage, MN 55378

P 800.582.6480 / 952.894.6280

F 877.894.6918 / 952.894.6918

A Fellenoord 130 5611 ZB EINDHOVEN, The Netherlands

P +31 (0)40 2668620

F +31 (0)40 2668615

Asia Pacific A Room 24F, Bloc

A Room 24F, Block D, Lily YinDu International Building LuoGang, BuJi Town, Shenzhen, CHINA.

深圳市布吉罗岗村百合银都国际大厦D栋24F

P +86-755-8996 9226

F +86-755-8996 9217

